

# **ERFURT-Novaboss**

4551, 4556, 4559, 4561, 4562, 4567, 4577, 4578

### **Product benefits**



PVC-free



Nonwoven adhesive



For walls and ceilings



Can be re-painted several times



EREUR

WÄNDE ZUM WOHLFÜHLEN

STRUKTUR- UND VLIESTAPETEN

Breathable



Excellent embossing stability



3-ply paper



Water vapourpermeable



Minimal consumption of paste

### How to use



**1.** Remove old wallpaper and paint. Smooth out rough base surfaces with plaster-based filler. Prime very absorbent base surfaces with solvent-free primer.



**4a.** Pasting by hand Cut lengths to the height of the wall plus a little extra and paste individually. Pay attention to the pattern repeat or



**6.** Allow all the lengths soak for around 15 minutes.



**9.** Do not overlap at outside corners. Cut precisely on the edge.



2. Ensure that the base surface is dry, clean, firm, absorbent and smooth. Mark the width of the wallcovering on the wall as a vertical line to aid hanging the first length perpendicular to the floor.



**4b.** Using a pasting machine Pull lengths through the pasting machine and cut. Pay attention to the pattern repeat.



7. Hang ERFURT-Novaboss with the seams butt jointed. Use a wallpapering brush or sponge roller to press out bubbles and folds.



**10**. When dry, apply high-quality emulsion paint (EN 13300-compliant). Preferably use satin matt or satin gloss paint.



3. Use nonwoven adhesive.



**5.** Fold the pasted lengths 2/3 to 1/3. Do not crease when folding.



**8.** Cut off excess wallpaper in the corners with a wallpapering palette knife and a Stanley knife or with scissors.

**Novaboss** 



## **Product Description**

#### **ERFURT-Novaboss**

4551, 4556, 4559, 4561, 4562, 4567, 4577, 4578

#### Manufacturer

ERFURT & SOHN KG • Hugo-Erfurt-Straße 1 42399 Wuppertal • GERMANY • www.erfurt.com

### Raw materials/Manufacture

All the above types of ERFURT-Novaboss wallpaper are white three-ply special embossed types of wallpaper.

The manufacturing process consists of gluing and embossing two layers of paper, finished in a special process with a third layer of paper that remains

All the above types of ERFURT-Novaboss wallpaper are manufactured in the same production process and differ only in terms of design.

There are no problems associated with the removal/disposal of ERFURT-Novaboss, as the natural raw materials are automatically returned to the ecosystem.

#### **Product data**

FRFURT-Novaboss 4551, 4556, 4562, 4577, 4578

- Roll dimensions: 10.05 m long x 0.53 m wide
- Carton content: 9 rolls

ERFURT-Novaboss 4559, 4561, 4567

- Roll dimensions: 10.05 m long x 0.53 m wide
- Carton content: 12 rolls

#### **Product features**

- Extremely structurally stable and insensitive to pressure due to three layers of paper
- Minimal consumption of paper with its flat rear side
- Its water vapour permeability as per DIN 52615 corresponds to a diffusion-equivalent air layer thickness of approx. 0.16 m
- Fire rating "B-s1,d0" according to EN 13501-1 corresponds to "B1" (fire-retardant) according to DIN 4102-1
- Free of PVC, plasticisers and solvents
- $\bullet$  No addition of heavy metal compounds or formal dehyde
- · Easy to remove after moistening with water
- Can be re-painted several times with commercially available paints

# Application/Handling

#### **Base surface**

ERFURT-Novaboss can be used on all interior base surfaces suitable for wallpapering. Ensure that the base surface is dry, firm, even, absorbent, clean, smooth and sufficiently even for the intended wallcovering. Remove old wallpaper and loose paint. Smooth out rough base surfaces with plaster-based filler. Prime smooth plaster with diluted paste. Prime highly absorbent base surfaces with solvent-free primer or paste. Please read BFS data sheets nos. 7 and 16.

#### Adhesive

Henkel: Solvite Ready to Roll, Delicate Wallcoverings Adhesive Pufas: Glutolin S15, Glutolin K10, Decotric MC Spezial, Decotric G20

#### Adhesion

Paste the lengths evenly, fold and leave to soak for 10 - 15 minutes. Do not crease when folding. Any bubbles that form during papering smooth out after drying. Carefully butt joint the lengths of wallpaper with a wallpapering brush. Do not use a seam roller. Remove surplus paste immediately.

### **Painting**

Once dry, apply emulsion paint with minimum wet abrasion class 3 (as per EN 13300) to ERFURT-Novaboss. High-quality satin gloss or gloss emulsion paint is preferable, as these paints highlight the textures better.

# **Ingredients/Test results**

ERFURT-Novaboss consists of paper fibres, cellulose and additives.

Dispose of painted ERFURT-Novaboss with normal household waste.

Its water vapour permeability as per DIN 52615 was certified by the ISEGA-Forschungs- und Untersuchungs-Gesellschaft mbH in Aschaffenburg,

